

MCB Boards, IP66, single and three-phase with details of Extension Boxes, Spreader Boxes, Meter Chambers and Rain Canopies (all factory fitted)

S040301P	DB266kWHr (125:5)	Fits all distribution boards with 125A incomers	Usually fitted to the underside of an MCB board
S040302P	DB266kWHr (200:5)	Fits all distribution boards with 200A incomers	